Face and Neck Massager

User Manual – HBM1000

Please read enclosed instructions carefully before using.

Introduction

The NuVita™ Face and Neck Massager is a unique and powerful non-invasive treatment that rejuvenates the most fundamental component of the human body – connective tissue – through gentle massaging, to help increase blood circulation to nourish and oxygenate tissue.

The NuVita™ Face and Neck Massager is ergonomically designed with an easily assembled – snap on – treatment cup. The device operates efficiently on 2-AA batteries.

Parts Identification:



Safety/Cautions:

Please read carefully before using.

If you are currently under the care of a physician for any skin condition, consult your physician before using the NuVita™ Face and Neck Massager.

Safety:

- Keep the device moving when using the device; don't let the device remain in one spot for too long.
- Regular cleaning of the filter will make sure that the device is working under appropriate treatment pressure for better efficiency.
- Keep the device away from children.
- The device is NOT waterproof and should NOT be submerged in water, used in the shower or bathtub.
- When not in use for more than 2 weeks, remove the batteries from the unit to preserve the device.

Warnings:

DO NOT USE the NuVita™ Face and Neck Massager if you:

- Have heightened skin allergies
- Are sunburned
- Have open wounds
- Recently underwent a chemical peel
- Having Microdermabrasion
- Recently underwent facial cosmetic surgery
- Have severe acne, serious skin conditions or infections

If any of these conditions apply to you, please consult with your physician before using the NuVita™ Face and Neck Massager. Do not share applicator with others; doing so can result in skin irritations or infections. We recommend not sharing the applicators with other users for hygienic purposes.

Preparation:

Preparing the Unit for Use:

1. Press the key up and remove battery cover.
2. Insert batteries inside the device.

   Note:

   - Match the +/- symbols as marked on the battery case.
   - Make sure your hands are dry before inserting the batteries.

3. Replace battery cover. Insert the upper part of the cover first, press on the lower part to snap cover into place.



Important Notes:

1. Batteries are to be inserted with the correct polarity.
2. Do not mix different make batteries.
3. Do not mix old and new batteries.
4. Remove dead batteries from the device as soon as possible.
5. Please comply with your local environmental protection agency's regulations for recycling batteries.
6. Do not submerge device into water.
7. Power off the device when not in use.
8. When not in use for more than 2 weeks, remove the batteries from the unit to preserve the device.

Operations:

Attention: Before each use, apply the unit on the forearm first to test the strength. If suction is weak, replace the batteries before using.



1. Make sure treatment cup is affixed to the device.
2. Push the blue On/Off button to activate the unit. To achieve best results, clean and remove any makeup from the area you will be massaging.
3. For optimal results, it is recommended that you apply some anti-aging cream on face and neck.
4. Gently move the unit by following these directions below:

A. Move from chin to under ear area

B. Move from chin to in front of ear area

C. Move from corner of mouth to sideburns

D. Move from under the nose to sideburns

E. Move from corner of the mouth to nose wings (side of nose)

F. Move from nose wing side to cheekbone

G. Move from lower forehead to upper forehead

H. Move from lower neck to upper neck

Cleaning and Storage:

Clean the unit and treatment cup after each usage.

Caution: Do not use any alcohol, acetone, petrol, abrasive cleaning agents, etc. to clean the plastic parts.

1. Use dry cloth to clean any residue remaining on the body of the device.
2. Remove treatment cup and flush clean with gentle soap and water.
3. Clean filter when necessary.
    a. Remove treatment cup
    b. Use a tool to remove filter cover
    c. Take out filter flush clean with warm water.
    d. Towel dry filter and filter cover and replace them.



Note: Because filter & filter cover are pretty tiny in dimension, pay attention not to miss them during cleaning.

4. Store the unit and parts in storage box until next use.

Maintenance and Replacements:

If treatment strength becomes weak and is not giving strong suction strength, insert new batteries and check device again for suction strength. If suction is still weak, thoroughly clean the filter. If this does not increase suction strength, the treatment head (filter) will need to be replaced. Contact your local dealer or retailer for a replacement filter - item # HBMF001.

Warranty:

This unit is under warranty to be free of defects in material and workmanship for one year from the date of original purchase. This warranty does not cover finishes, nor does it cover damage resulting from accident, misuse, neglect, dirt, water, temperature, unreasonable use, servicing performed or attempted by unauthorized service agencies or units that have been modified.